

# **ASSEMBLY INSTRUCTIONS**


ITEM No.: 2011




Assembly video can be found on our website at www.arrowcabinets.com in the Video Section. Questions? Call 1-800-533-7347 press 1 or Email: cs@arrowcabinets.com








Screw cam bolts all the way in.



# **PARTS LIST**

ITEM	DESCRIPTION	QTY.
A A1 A2 G X Z Y1 Y2 D	Top panel Platform Cover Platform Bottom Left Side Panel Right Side Panel Left Inside Panel Right Inside Panel Back	1 1 1 1 1 1 1
E V1 V2 O	Shelves Left Door Right Door Insert Holder	2 1 1 1


# LIFTER PART LIST



# PARTS LIST


ITEM	DESCRIPT	ON QTY.	ITEM	DESCRIPTIO	ON QTY.
c1 d1 c2 p1 t1 r3 s4 m	6*35 Cam Be 8*30 Dowel   (58") Cam Cov Threaded De Castor 14mm Spane 3.5*10 Screen Magnet 4*6 Screw	oin 28 ver 32 owel Pin 8 5 ner 1	h h1 b2 b4 s1 g1 g1 s2 s20	Handle Hinge Fix Bolt Washer 4*14 Screw Hinge Body tog Hinge Stand 3.5*25 Screw 6*50 Fix Bolt	2 2 4 4 4 16 dy & stand arrive 2 2 2 3 2
c1 6 <sup>-</sup>	*35 Cam Bolt-30	d1 8*30 Dowel Pin	n-28 c2	(58")Cam Cover-32	tl Castor-5
r3 14	mm Spanner-1	s1 4*14 Screw-	32 h	Handle-2	b2 4*36 Fix Bolt-4
b4	Washer-4	p1 Threaded Dow	vel Pin-8 h	n1 Hinge-2	s7 4*6 Screw-4
g	1 Hinge Body-2  *g1 pieces arrive attac	g1 Hinge Stand	d-2 s20	0 6*50 Fix Bolt-2	m Magnet-1
s2	2 3.5*25 Screw-3	ş s4 3.5*10 Screv	v-2	Pre-ii	nstalled parts






## Preparing panels A,G,D,X,Z,Y1,Y2,V1 and V2


- 1. Insert cams bolts(c1) into panels A,G,X,D and Z as illustrated above.
- 2. Insert dowel pins (d1) to panels X,Z,Y1,Y2 and D as illustrated above.
- 3. Fix handles (h) to panels V1 and V2 with fix bolts(b2) as illustrated above.
- 4. Fix hinge bodies (g1) to panels V1 and V2 with screws (s1) as illustrated above.
- 5. Screw the metal bar support on to Top Panel A using the 2 screws. Place in pre-drilled holes at front on panel.
- 6. Fix Hinges(h1) with screws(s1) into panels V1,V2 as illustrated above.
- 7. Attach locking casters(t1) to panel G by using the spanner tool(r3).
- 8. Attach magnet plate included with m on to panel V1 by using s4 screws into predrilled holes in corner of panel.
- 9. Attach the door magnet (m) to Top Panel A using (s1) screws as illustrated above.



1. Fix Lifter Rail (left) to Y1 panel with \$1 screws following predrilled holes as shown on the illustration above.




1. Fix Lifter Rail (right) to Y2 panel with s1 screws following predrilled holes as shown on the illustration above.



#### Panel D,X, and Z assembly.


1.Insert cam bolts on panel X and Z into cams on panels D and tighten in a clockwise direction as illustrated above.

## STEP 5




#### Panel Y1 and Y2 assembly.

1.Insert cam bolts on panel Y1 and Y2 into cams on panels D and tighten in a clockwise direction as illustrated above.




#### Panel O assembly.

1.Insert cam bolts on panel G into cams on panels O and tighten in a clockwise direction as illustrated above.




- 1.Insert cam bolts on panel G into cams on panels X,Z,D,Y1 and Y2 and tig a clockwise direction as illustrated above.

  2.Insert screw on panel G into holes on panels Z and tighten in a clockwise on panel G into cams on panels X,Z,D,Y1 and Y2 and tighten in
- direction as illustrated above.




1. Fix Lifter to A2 panel with s1 screws following predrilled holes as shown on the illustration above.

#### STEP 9




#### Mounting the Lifter Assembly.

- 1.Position lifter onto side rails using plastic guides; by lowering the lifter make sure the cable is catch onto the rail tabs on both sides. See illustration above.
- 2. When lifter pushed to first lock position remove a small wooden block that will be released from lifter.





1.Insert cam bolts on panel A into cams on panels X,Z,D,Y1 and Y2 and tighten in a clockwise direction as illustrated above.

## STEP 11



- 1.Press in pegs with flat surface facing upwards at the same level on panels and Y1.
- 2.Slide shelf E with cut in grooves (if available) downwards on top of p1 pegs.





Door panel V1,V2 assembly.

1. Attach door assembly V1 and V2 to cabinet with screws S7 to panel Z runners as illustrated above.

You have now successfully completed the assembly on item:

ITEM NO.: 2011

