



Item No. 38431


ADJUSTABLE Home Hobby & Craft Table Assembly Instructions



www.sullivans.net/usa



ADJUSTABLE Home Hobby & Craft Table Instructions



1. Insert all 6 SHORT BEAMS (M) into RECTANGULAR BODY (N) & SWING ARMS (O).


2. Lock **SHORT BEAMS (M)** into place using **ADJUSTING KNOBS (G)**.


3. Insert 2 CASTERS (K.1) into SWING ARMS (O) and 2 CASTERS (K.1) 1 on each RECTANGULAR BODY (N), use 2 LOCKING CASTERS (K.2) one on each RECTANGULAR BODY (N) at opposite ends (fig. 1), use OPEN END WRENCH (I) to tigthen CASTERS and LOCKING CASTERS in place.

4. Align **RECTANGULAR BODY** (**N**) one in front of the other, connect them using **LONG BEAMS** (**L**) with holes facing upward & 6 **HEX-HEAD SCREW** (**D**) tigthen using **ALLEN KEY** (**H**).


5. Connect SWING ARMS (O) to RECTANGULAR BODY (N) using 2 HEX-HEAD SCREW (E), tigthen with ALLEN KEY (H).

6. Connect **SMALL BOARDS (P)** on bottom tiers of assembly (fig. 2) using **HEX-HEAD SREWS (C)**, tigthen with **ALLEN KEY (H)**.






ADJUSTABLE Home Hobby & Craft Table Instructions



7. Place LARGE BOARD (R) and MEDIUM BOARD (Q) face down on flat surface, connect them using HINGES (F) facing UP and HEX-HEAD SCREWS (B) tigthen using ALLEN KEY (H).



8. Position **STOPS (J)** so that they will connect with **SWING ARMS (O)** when open, use pre-drilled holes and **PHILLIPS HEAD SCREWS (A)**.


METAL ASSEMBLY

(H)

9

9. Leave the **BOARD ASSEMBLY** on a sturdy flat surface, close and flip the **METAL ASSEMBLY** and connect using **5 HEX-HEAD SCREWS (C)** tigthen using **ALLEN KEY (H)**.

10. Once table is assembled height can be adjusted by folding down the table, then while holding on to **BOARD ASSEMBLY** carefully remove **ADJUSTING KNOBS** one at a time, then place them at desired height.



SAFETY & MAINTENANCE

This table is not a toy - DO NOT let children play on, under, or around it. DO NOT place more than 30 pounds on the table wings. To clean table, use a cloth or sponge with mild soap. (NEVER use anything abrasive). NEVER rest a hot iron directly on the surface.

For ironing, use the Home Hobby Table Ironing Cover - in stores everywhere.

Sullivans USA, Inc 4341 Middaugh Ave. Downers Grove, IL 60515 (800) 862-8586 Fax: (630) 435-1532 M.T. Sullivan & Co. Pty. Ltd. 40 Parramatta Road Underwood, Brisbane, Queenland Australia Sullivans Enterprises (N.Z.) Ltd. 28 Sir William Ave. East Tamaki, Auckland New Zealand Sullivans USA, Inc. will replace any missing or defective parts within 30 days or purchase date. Fax a dated receipt to (630) 435-1532 along with your request. This policy does not apply to Damages due to shipping. For further assistance, please call (800) 862-8586

BOARD ASSEMBLY

ł

PLEASE NOTE: Our 30-day No Charge replacement policy for parts does not apply to items sold AS IS, CLEARANCE, CLOSEOUT, FINAL SALE, ETC. Any parts requested under these circumstances will be charged to the customer, including shipping charges. Shipping charges for replacement parts to Alaska, Hawaii or any point outside of The Contiguous United States are not covered under our policy.