

SNAP HOOP

COMPATIBILITY CHART

SINGLE NEEDLE MACHINES

	Snap Hoop								Snap Hoop Monster									
	4in x 4in	4.5in x 6.75in	5in x 7in	120 x 120mm	145 x 255mm	150 x 400mm	7in x 12in	8in x 8in	260 x 200mm	4in x 4in	5in x 7in	120 x 120mm	145 x 255mm	150 x 400mm	7in x 12in	8in x 8in	260 x 200mm	260 x 400mm
Baby Lock Machine Models																		
Destiny BLDY	• LS3		• LS1			• LS5	• LS2		• LM3	• LM1					• LM5	• LM2		
Ellageo Plus ESG, ESG2, ESG3			• LS4								• LM4							
Ellisimo (all versions)	• LS3		• LS1			• LS5	• LS2		• LM3	• LM1				• LM5	• LM2			
Ellegante (all versions)	• LS3		• LS1			• LS5			• LM3	• LM1				• LM5				
Ellure BLR, Ellure Plus BLR2, BLR3			• LS6							• LM6								
Emore BLMR			• LS6							• LM6								
Journey, Spirit, Unity	• LS3		• LS1			• LS5			• LM3	• LM1				• LM5				
Bernina Machine Models																		
Artista 180, 185E, 200E, 560, 580, 630E, 730E					• RS1	• RS2							• RM1	• RM2				
Artista 750, 780, 830, 880					• RS1	• RS3							• RM1	• RM3			• RM4	
Aurora 430E, 440QEE, Anniversary Edition					• RS1	• RS2							• RM1	• RM2				
Brother Machine Models																		
8200, 8500			• LS6							• LM6								
Dream Maker XE, Dream Weaver, Dream Weaver XE	• LS3		• LS1			• LS5			• LM3	• LM1				• LM5				
Duetta (all versions)	• LS3		• LS1			• LS5			• LM3	• LM1				• LM5				
Innov-is 1000, 1200, 1250D			• LS6							• LM6								
Innov-is 1500D, 2500D, 2800D	• LS3		• LS1							• LM3	• LM1							
Innov-is 3500, 4000, 4000D, 4500, 5000, 6700	• LS3		• LS1			• LS5			• LM3	• LM1				• LM5				
PE-700, 700II, 750D, 770, 780D			• LS6							• LM6								
Quattro (all versions)	• LS3		• LS1			• LS5	• LS2		• LM3	• LM1				• LM5	• LM2			
XV8500 Dream	• LS3		• LS1			• LS5	• LS2		• LM3	• LM1				• LM5	• LM2			
ULT 2001, 2002, 2003			• LS4							• LM4								
Husqvarna-Viking Machine Models																		
Designer Diamond Series, Royal & Deluxe					• HS1				• HS2			• HM1				• HM2		
Designer Ruby, Ruby Deluxe, Topaz 20, 30, 50					• HS1				• HS2			• HM1				• HM2		
Designer Topaz 25					• HS1							• HM1						
Pfaff Machine Models																		
Creative 2.0, 3.0, 4.0, 4.5 5.0, 5.5, Performance, Vision					• HS1				• HS2		• HM1					• HM2		
Singer Machine Models																		
Futura CE-100, 150, 200, 250, 350			• NS1															
SES1000, 2000			• NS1															

SNAP HOOP

COMPATIBILITY CHART MULTI NEEDLE MACHINES

	Snap Hoop Quick Snap				Monster Quick Snap				Quick Snap	Multi Needle Monster		
	4in x 4in	5in x 7in	4in x 4in & 5in x 7in	11.75in x 7.875in	4in x 4in	5in x 7in	4in x 4in & 5in x 7in	11.75in x 7.875in	15 frame set	5in x 7in	8in x 12in	8in x 8in
Baby Lock Machine Models												
All models - for use with Quick Snap frame set	• GQ2	• GQ3	• GQ4	• GQ1	• GH2	• GH3	• GH4	• GH1				
BMP6, BMP8, BMP9, BMP10, EMP6, BND9, BND9-2 (with adapter)	• LQ2	• LQ3	• LQ4	• LQ1	• LH2	• LH3	• LH4	• LH1	• GS1			
BMP6, BMP8, BMP9, BMP10, EMP6, BND9, BND9-2 (for use with arms)										• GM1	• GM3	
Enterprise BNT10, BNT10L (with adapter)	• LQ2	• LQ3	• LQ4	• LQ1	• LH2	• LH3	• LH4	• LH1	• GS1			
Enterprise BNT10, BNT10L (for use with arms)										• GM1	• GM3	• GM2
Bernina Machine Models												
All models - for use with Quick Snap frame set	• GQ2	• GQ3	• GQ4	• GQ1	• GH2	• GH3	• GH4	• GH1				
Happy Voyager, Journey (with adapter)	• RQ2	• RQ3	• RQ4	• RQ1	• RH2	• RH3	• RH4	• RH1	• GS3			
Brother Machine Models												
All models - for use with Quick Snap frame set	• GQ2	• GQ3	• GQ4	• GQ1	• GH2	• GH3	• GH4	• GH1				
PR600, 600II, 600CII, 620, 650, 655 (with adapter)	• LQ2	• LQ3	• LQ4	• LQ1	• LH2	• LH3	• LH4	• LH1	• GS1			
PR600, 600II, 600CII, 620, 650, 655 (for use with arms)										• GM1	• GM3	
Entrepreneur Pro 1000, 1000e (with adapter)	• LQ2	• LQ3	• LQ4	• LQ1	• LH2	• LH3	• LH4	• LH1	• GS1			
Entrepreneur Pro 1000, 1000e (for use with arms)										• GM1	• GM3	• GM2
Janome Machine Models												
All models - for use with Quick Snap frame set	• GQ2	• GQ3	• GQ4	• GQ1	• GH2	• GH3	• GH4	• GH1				
MB4, Melco EP4 (with adapter)	• JQ2	• JQ3	• JQ4	• JQ1	• JH2	• JH3	• JH4	• JH1	• GS2			