


Dear Valued Customer;
Congratulations and thank you for purchasing our high quality Sylvia Cabinet.

To access the different heights of the sewing machine platform, press firmly on the top until a “click” is heard, release slightly, another “click”, then press to lower. If already low, press to release and the platform will ease up to a higher position.



Loosen both 8mm nuts to adjust height of machine to approximately 1/8" above insert level. Tighten nuts.