

# Bandicoot Assembly Instructions



## Bandicoot Sewing Cabinet

Congratulations on the purchase of your new Bandicoot Sewing Cabinet. Every effort has been taken to ensure your complete satisfaction with this custom designed product. For your convenience the Bandicoot Sewing Cabinet is supplied in three ready to assemble packs.

## Helpful Assembly Hints

Read the instructions carefully before starting. Check to see that all the parts are included. Work in a spacious area preferably on a carpet or soft surface. You will need a phillips head and flat head screw driver for the assembly. A cordless drill is preferable. Ensure the phillips head screwdriver fits neatly and fully engages the screw head. Failure to do this may result in screw damage. Make sure you tighten all the screws securely and tap dowels all the way in.

## Warranty Information

G-day mate! We warranty our product for 5 years from date of shipment for manufacturer's defects and shipping damage within the first 15 days. The warranty does not cover damage caused by abuse, mis-use, alteration, accident, or neglect of the product. The warranty does not cover damage caused by moving the cabinet fully loaded. Under the terms of this warranty the repair and replacement of any parts shall be at the discretion of the company or their designated representative.

## Replacement Part Shipping Policy

To help protect our valuable resources, we ship all replacement parts out at the same time. This procedure lessens the use of packaging materials and fossil fuels used in transportation keeping our world for all kangaroos and the people like you a cleaner place. Please help us in this endeavor by reviewing all parts in all boxes for damage before calling or e-mailing us to report damage. We adhere to our environmental philosophy by only shipping replacement parts out 1 time for free. Future parts requests will be billed at the customer's expense.

## Cabinet Care

Your Bandicoot Sewing Cabinet normally requires a minimum amount of maintenance, however the following points are worth noting:

**CLEANING** - To remove marks and enhance the surface, wipe over with a general purpose cleaner.

**CAUTION** - Do not use ammonia based cleaning agents. Do not use harsh chemicals or abrasive cleaners. The surface can be wiped with a damp cloth but should be dried quickly.

If you have missing or damaged parts please call Kangaroo Kabinets at 1-800-533-7347


or email us at: [cs@kangarookabinets.com](mailto:cs@kangarookabinets.com)

Also visit our website: [www.kangarookabinets.com](http://www.kangarookabinets.com)

















## Bandicoot Assembly Instructions

### BANDITCOOT SEWING CABINET PANELS AND THEIR DESCRIPTIONS

Note: Hole positions helps with panel orientation.



COMPONENTS	DESCRIPTION	QTY	COMPONENTS	DESCRIPTION	QTY
	Cam Ø15mm	10		Hinge Mounting Plate	4
	Cam Bolt 34mm	10		Hinge	4
	Dowel Ø8 x 30mm	16		Castor Washer	4
	Screw Ø5 x 50mm C/S	6		Spanner	1
A	Screw Ø3.0 x 15mm C/S	36		Castor Ø50mm Locking	2
H	Varianta Screw (Hinge)	8		Castor Ø50mm	2
	Foam 85x40x18 Grey	2		Lock Striker	1
	Glue Bottle	2		Bow Handle & Screws	2
	Door Hook (75mm)	2		Lifter Rail R/H	1
	Cover Cap	6		Lifter Rail L/H	1
	Bobbin Holder	2		Lifter (612mm)	1
	Small Bucket	2			


 <p>Cam Bolt</p> <p><b>Assembly Steps</b></p> <ol style="list-style-type: none"> <li>1. Screw Cam Bolts into the Bottom as shown. (Use Smaller Ø holes)</li> </ol>	<h2>1. Bottom Pre-Assembly</h2>  <p>Cam Bolt</p> <p>B</p>
 <p>Cam Bolt</p>  <p>Lock Striker</p>  <p>Screw A Ø3 x 15mm C/S</p> <p><b>Assembly Steps</b></p> <ol style="list-style-type: none"> <li>1. Screw Cam Bolts into the Top as shown. (Use Smaller Ø holes)</li> <li>2. Fit Lock Striker using Screw A Ø3x15mm C/S</li> </ol>	<h2>2. Top / Flap Pre-Assembly</h2> <p>STEP 1</p>  <p>Cam Bolt</p> <p>A</p> <p>Note: Orientation of Lock Striker</p> <p>Screw A Ø3x15mm</p> <p>Lock Striker</p>
 <p>Cam Ø15mm</p>  <p>Dowel Ø8 x 30</p>  <p>Hinge</p>  <p>Varianta Screw (x8)</p>  <p>R/H Lifter Rail</p>  <p>Screw A Ø3 x 15mm C/S</p> <p><b>Assembly Steps</b></p> <ol style="list-style-type: none"> <li>1. Press Cams into holes as shown.</li> <li>2. Insert Dowels with 2 to 3 drops of Glue</li> <li>3. Secure Hinges in place with Screw H Ø6x15mm</li> <li>4. Fit R/H Lifter Rail using Screw A Ø3.5x15mm P/H</li> </ol>	<h2>3. Left &amp; Right Hand End Pre-Assembly</h2> <p>Note: Arrow on cam points towards closest edge.</p> <p>STEP 1</p>  <p>Cam</p> <p>C</p> <p>STEP 4</p>  <p>Screw A Ø3x15mm</p> <p>Right Hand Lifter Rail</p> <p>D</p> <p>STEP 2</p>  <p>Dowel</p> <p>STEP 3</p>  <p>Varianta Screws</p>




Hinge Mounting Plate



Door Hook



Small Bucket



Bobbin Holder


Screw A Ø3 x 15mm C/S

#### Assembly Steps

1. Screw on Hinge Mounting Plates using Screw A Ø3.5x14mm C/S
2. Tap in Door Hooks
3. Screw on Small Buckets using Screw A Ø3x15mm C/S
4. Screw on Bobbin Holders using Screw A Ø3.5x15mm P/H


### 4. Door Pre-Assembly

#### STEP 2




Door Hook

#### STEP 3



Screw A Ø3x15mm


#### STEP 1



Screw A Ø3x15mm

Hinge Mounting Plate

#### STEP 4




Bobbin Holder

Screw A Ø3x15mm

### 5. Division / Shelf Pre-Assembly



Dowel Ø8 x 30mm



L/H Lifter Rail

Screw A Ø3 x 15mm C/S


#### Assembly Steps

1. Insert Dowels with 2 to 3 drops of Glue.
2. Screw on L/H Lifter Rail using Screw A Ø3.5 x 15mm P/H


#### Note:

Rail will be level with top edge


#### STEP 2.



Screw A Ø3x15mm




DOWEL



F

Division




Shelf


H

DOWEL


## 6. Bottom, Back, R/H End Assembly




Bottom



R/H End



Back




Screw Ø5 x 57mm




Cover Cap

### Assembly Steps


1. Place 2 to 3 drops of Glue in Dowel holes in the Bottom.
2. Insert the Cam Bolts into the R/H End and secure.
3. Screw the Back to the R/H End using Screws Ø5x57mm C/S.
4. Push in Cover Caps




## 7. Division & Shelf & L/H END Assembly




Division



Shelf






L/H End



### Assembly Steps


1. Place 2 to 3 drops of Glue in dowel holes in the L/H End and Division and insert Shelf.

## 8. Division, Shelf Assembly






### Assembly Steps

1. Place 2 to 3 drops of Glue in the dowel holes in the Bottom then locate L/H End and Division over Cam bolts and insert. Secure by turning Cams a half turn clockwise.
2. Screw the Back to the L/H End using Screws Ø5x57mm C/S.
3. Push in Cover Caps




## 9. Lifter, Lifter Board Pre-Assembly



### Assembly Steps

1. Screw the Lifter to the Lifter Board using Screw A Ø3.4 x 15mm C/S


**Note:**  
The Lifter orientation on Lifter Board





## 10a. Lifter, Cabinet Assembly

Step 1.





Lifter Board Assembly

### Assembly Steps

1. Position Lifter guides over Rails and gently slide the Lifter into position.

Note:

Ensure all 4 plastic guides (2 on each side are positioned correctly.)



### Assembly Steps


1. Loop Cable through Metal Tab on Lifter Rails & secure.
2. Push Lifter down and click into first stop position.

Note:



When the Lifter is clicked into this first stop position a small block of timber will disengage from the rear of the Lifter.

Discard block

## 10b. Lifter Cable Attachment



## 11. Top Assembly



### Assembly Steps

1. Place 2 to 3 drops of glue in the Dowel holes in the Top Assembly
2. Align the Top Assembly Cam Bolts with the Ends and Division and insert.
3. Half turn the Cams Clockwise to tighten
4. Once complete lift the cabinet onto its Top.


**Note:** It may require 2 people to lift the cabinet.

**A.** Insert  
Cam Bolts




STEP 1

**B.** Note:  
Half turn clockwise  
to tighten

STEP 2




## 12. Castor Assembly



### Assembly Steps

1. Place Castor Washer over the Castor Thread and then screw into the Bottom and tighten with the Spanner.
2. Screw the Bottom to the Back using Screw Ø5x50mm
3. Rotate the Cabinet upright.

**Note:** It may require 2 people to lift the Cabinet.



STEP 2

Screw  
Ø5 x 50mm

Cover Cap

STEP 1



Spanner

Castor  
Washer

Castor Ø50mm




### 13. Left & Right Hand Door Assembly



#### Assembly Steps

1. Locate and slide the Hinge onto the Hinge Plate Screw and snap into place.
2. Repeat for other hinges.



### 14. Hinge Adjustment

 Screw B Ø3.5 x 14mm C/S

#### Hinge Adjustment Steps


##### Vertical

1. Partially loosen the Hinge Screws on one Door.
2. Lift the Door until it is 2mm from the Top and re-tighten the Hinge Screws.


##### Horizontal

1. Partially loosen the Hinge Bracket screws on the Door.
2. Move the Door in or out to adjust the Gap between the Doors when closed.
3. Re-tighten the Hinge Bracket Screws.
4. When Doors are adjusted fit Screw B Ø3.5x14mm C/S to secure Hinges.


#### STEP 1




#### Vertical Adjustment





#### STEP 2



#### Horizontal Adjustment





## 15. Left & Right Hand Door Assembly



### Assembly Steps

1. Screw on Bow Handles as shown

## 16. Opening Flaps Procedure



### Assembly Steps

1. Open the Door and rest the Flap on the Door.
2. Insert the Door Hook into the Flap Bush to secure the Door & Flap

**Note:** Door must fully open before the Flap is opened.

3. Insert Foam into Bobbin Holder